

# Infinix

## **True Wireless Earphones XBuds 3 WE**

Model: XE29

User Manual

Hereby, INFINIX MOBILITY LIMITED.

Declares that this True Wireless Earphones is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

Please read this manual carefully before using this product.

# 1. What's In The Box

EN



Charging case X1




True Wireless Earbud X2




USB-C Cable X1

# 2. Product Overview



- ① Multi-Function Button(MFB)
- ② Earbud Indicator
- ③ Microphone
- ④ Type-C Charging Port



- ⑤ Left Earbud
- ⑥ Right Earbud
- ⑦ Case Status Indicator

# 3. Using Your Earbuds

## 3.1 REMOVE THE PROTECTIVE FILM

1 Protective film



## 3.2 CHARGING

1



Put the earbuds back to the charging case.

2



Fully charge the case.



Flash red

Being charged



Light Off

Fully charged

## 3.3 POWER ON/OFF

ON



Open the charging case lid, then the earbuds will automatically power on.

OFF



Put the earbuds back into the charging case and close the lid to power off automatically.

## 3.4 PAIRING



Earbuds will power on and enter pairing mode automatically when taking out the earbuds from charging case.

- Make sure the distance of the earbuds and your device is less than 1 metre/3.3 feet at the first time of connection.
- When turned on, the earbuds will automatically connect to the last connected device if available, If not, the earbuds will enter pairing mode.
- Under any abnormal condition, put the earbuds back into the charging case with the lid closed, then take out again after 15 seconds.
- When the left earbud and right earbud are not paired automatically with status indicators flashing white on both earbuds, simulatanenously tap 6 times on both earbuds to manually enter TWS pairing mode.

## 3.5 DOWNLOAD THE WELIFE APP



1. Scan the QR code to quickly download the Welife app for preferred sound effects, customized control, customer support, and more(only for Android 7.0+ devices).
2. Power on the earbuds, then open the Welife app and tap the "Add Device" to pair the earbuds with the app.

### **Multiple Sound Effects to Enjoy:**

Support Bass Booster, Treble Booster, Vocal Booster, Default mode (Normal mode). Choose the one that suits you best.

### **Quick Activation of Game Mode:**

Enable game mode quickly in the app to achieve better synchronization of audio and video for an enhanced gaming experience.

### Touch Control Customization:

Discover or customize the functions triggered with earbud touch controls. Answering calls and controlling music are at your fingertips.

### Quick Connection Pop-up:

It enables auto pop-up for earbuds connection and supports custom pop-up themes. This feature is supported by many phone brands. For Infinix phones, customization of pop-up themes is only available for those running XOS 14 or later versions.

## 3.6 RESET



(Try the following steps if you fail pairing between two earbuds, or between earphones and device)

1. Clear pairing record between the earbuds and your device in the bluetooth pairing list on your device.
2. Take out the earbuds from the charging case, simultaneously tap four times and then long press on both MFB button within three seconds to clear the pairing record and enter the pairing mode automatically.

## 3.7 CONTROLS

### MUSIC



X2

Tap twice on one earbud

▶ || Play/Pause



2"

Press and hold for 2 seconds on the left earbud

◀ Previous Track



2"

Press and hold for 2 seconds on the right earbud

▶ Next Track

## CALL

---



Tap twice on one earbud



Answer/End a call

---



Press and hold for 2 seconds on one earbud



Reject

---

## OTHER

---



Tap three times on the left earbud(only TWS mode)



Switch Game mode

---



Tap three times on the right earbud



Activate Voice Assistant

---



Tap once on the left earbud



Decrease the volume

---



Tap once on the right earbud



Increase the volume

---



Tap four times and then long press the MFB button within three seconds on both earbuds (power on status)

Reset

---

# 4. Product Specification

---

Input

5V<sup>---</sup>500mA

---

Speaker Driver

Φ13mmx2

---

Battery Capacity

35mAhx2(earbuds), 400mAh(charging case)

---

Impedance

32Ω

---

Charging Time	Approx 1.5 hours (earbuds). 2.5 hours (charging case)
Play-time	Up to 6 hours (Totally 25 hours with the charging case)
Talk time	Up to 5 hours
Bluetooth Range	10m/33ft
Rated Output Power	5mW
Frequency Response	20Hz-20KHz

## CONSIDERATE HINTS

1. Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing.
2. When encounter any fault during operation, please cut off the power supply and disconnect the type-C cable to prevent further damage to the product or other components.
3. The Wireless transmission range or connectivity could be affected by low battery power, In that case, please recharge immediately.

## ATTENTION

Use original or certified cables.

Do not expose to the liquids.

Do not disassemble.

Avoid dropping.

Avoid extreme temperatures.

Do not use the product outdoors during a thunderstorm.

Do not use any corrosive cleaner/oil to clean.

# CAUTION

1. Use carefully with the earphone, maybe excessive sound pressure from earphones and headphones can cause hearing loss.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
  - disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
  - leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
  - a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
3. EUT Temperature: 0 C ~ +45 C (Standalone). 0 C ~ +40 C (with adapter).
4. To prevent possible hearing damage, do not listen at high volume levels for long periods.



High sound pressure with hearing damage risk.  
Do not listen at high volume levels for long periods.

## **Frequency Range(RF):**

BT: 2400-2483.5MHz (TX/RX);

## **Max. Of Transmit power:**

BT(EDR): 8.48 dBm

BLE:2.63 dBm

## **EU DECLARATION OF CONFORMITY**

The full text of the EU declaration of conformity is available at the following internet address:

<https://www.infinixmobility.com/care/declaration>



# Infinix

## True Wireless Earphones XBuds 3 WE

Model: XE29

Instrukcja obsługi

Niniejszym INFINIX MOBILITY LIMITED  
deklaruje, że te słuchawki są zgodne z wymaganiami i innymi  
stosownymi postanowieniami dyrektywy 2014/53/UE.  
Przed rozpoczęciem korzystania ze słuchawek należy uważnie  
przeczytać niniejszą instrukcję.

# 1. Zawartość opakowania **PL**



1x Etui ładujące




2x słuchawki




1x kabel USB-C

## 2. O produkcie



- 1 Przycisk wielofunkcyjny (MFB)
- 2 Diody pokazujące status urządzenia
- 3 Mikrofon
- 4 Złącze typu USB-C



- 5 Lewa słuchawka
- 6 Prawa słuchawka
- 7 Diody pokazujące tryb pracy etui

# 3. Jak używać słuchawek

## 3.1 Usuń folię ochronną

1 Folia ochronna



## 3.2 Ładowanie słuchawek

1



Umieść słuchawki  
w etui ładującym

2



Naładuj etui do 100%



Czerwone światło migające

Ładowanie etui



Dioda zgasła

Naładowane

## 3.3 Włączanie i wyłączenie

ON



●

Włączanie (ON)  
Otwórz etui,  
słuchawki włączą  
się automatycznie.

OFF



●

Wyłączenie (OFF)  
Umieść słuchawki  
w etui i zamknij  
klapkę. Słuchawki  
zostaną wyłączone  
i zaczną się  
ładować.

## 3.4 Parowanie



Słuchawki douszne włączą się i przejdą w tryb parowania automatycznie po ich wyjęciu słuchawek z etui-ładowarki.

- Upewnij się, że odległość między słuchawkami, a urządzeniem z którym chcesz je sparować jest przy pierwszym parowaniu mniejsza niż 1 metr.
- Po włączeniu słuchawki douszne automatycznie połączą się z ostatnim zapamiętanym urządzeniem, jeśli jest ono dostępne. Jeśli nie, słuchawki wejdą w tryb parowania.
- W razie problemów z parowaniem, warto schować słuchawki do etui na 15 sekund, następnie ponowić próbę.
- Gdy lewa i prawa słuchawka nie parują się, a wskaźniki stanu migają na biało, należy jednocześnie puknąć 6 razy na obu słuchawkach, aby ręcznie przejść do trybu parowania TWS.

## 3.5 Pobierz aplikację Welife



1. Zeskanuj kod QR, aby szybko pobrać aplikację Welife. W niej ustawisz preferowane efekty audio, tryb wyciszania hałasu, znajdziesz pomoc i znacznie więcej (tylko dla urządzeń z systemem Android 7.0 lub wyższym).
2. Włącz słuchawki douszne, następnie otwórz aplikację Welife i stuknij przycisk Dodaj urządzenie, aby połączyć aplikację ze słuchawkami.

### **Zestaw efektów dźwiękowych:**

Do wyboru mamy wiele ulepszeń, w tym Bass Booster, Treble Booster, Vocal Booster, itp.

### **Szybka aktywacja trybu gry:**

Szybkie włączenie trybu gry w aplikacji służy do uzyskania lepszej synchronizacji dźwięku i obrazu, co przekłada się na lepsze wrażenia w grze.

### **Własna kontrola gestami:**

Odkryj i korzystaj z własnych gestów sterujących. Dzięki interfejsowi dotykowemu masz pełną kontrolę w zasięgu dłoni.

### **Szybkie funkcje:**

Aplikacja wyświetla automatyczne wyskakujące okienka z opcjami połączenia słuchawek i obsługuje niestandardowe motywy systemowe. Funkcja jest obsługiwana przez wiele marek telefonów. W przypadku przypadku telefonów Infinix dostosowywanie motywów jest dostępne dla telefonów z systemem XOS 14 lub nowszym.

## **3.6 Reset i ustawienia fabryczne**



Wypróbuj następujące kroki, jeśli parowanie z urządzeniem lub między słuchawkami nie powiedzie się.

1. Wyczyść listę sparowanych akcesoriów na swoim urządzeniu.
2. Jeśli lewa i prawa słuchawka nie sparują się automatycznie, a wskaźniki stanu migają na niebiesko na obu słuchawkach, stuknij jednocześnie 6 razy na obu słuchawkach, aby ręcznie przejść do trybu parowania TWS.

## **3.7 Sterowanie**

### **MUZYKA**



Dwa stuknięcia w jedną słuchawkę



Naciśnięcie i przytrzymanie lewej słuchawki przez 2 sek.



Naciśnięcie i przytrzymanie prawej słuchawki przez 2 sek.



## ROZMOWA

---



Jedno stuknięcie w jedną słuchawkę



Obiór i zakończenie połączenia



Dotknięcie i przytrzymanie jednej słuchawki przez 2 sekundy



Odrzucenie połączenia

## INNE

---



Trzy stuknięcia na lewej słuchawce (tylko w trybie TWS)



Tryb gry



Trzy stuknięcia na prawej słuchawce



Aktywacja asystenta głosowego



Jedno stuknięcie lewej słuchawki



Ciszej



Jedno stuknięcie prawej słuchawki



Głośniej



4 stuknięcia obu słuchawek i przytrzymanie przycisku na etui przez 3 sekundy

Reset

## 4. Cechy urządzenia

---

Zasilanie

5V --- 500 mA

Głośnik

Φ13 mm x2

Baterie

35 mAh x2 (słuchawki), 400 mAh (etui)

Oporność

32Ω

Czas pracy	Do 5 godzin, 25 godzin z ładowaniem z etui
Czas ładowania	Ok. 1,5 godziny (słuchawki), Ok. 2,5 godziny (etui)
Czas rozmów	Do 5 godzin
Zasięg Bluetooth	10 m
Znamionowa moc wyjściowa	5 mW
Pasma	20 Hz-20 KHz

## Wskazówki dotyczące bezpieczeństwa

1. Nie należy używać długo wysokich poziomów głośności, ponieważ może to skrócić żywotność produktu lub uszkodzić słuch.
2. W przypadku napotkania jakiegokolwiek usterki podczas pracy, należy odłączyć zasilanie i odłączyć kabel, aby zapobiec uszkodzeniu produktu lub innych urządzeń.
3. Niski poziom naładowania baterii może mieć wpływ na zasięg bezprzewodowy. W takim przypadku należy ją niezwłocznie naładować.

## UWAGA

Należy używać wyłącznie sprawdzonych kabli.

Nie wystawiać na działanie płynów.

Nie rozbierać.

Unikać uszkodzeń fizycznych.

Unikać ekstremalnych temperatur.

Nie używać produktu na zewnątrz podczas burzy.

Do czyszczenia nie używać żrących środków czyszczących/olejów.

# Ostrożnie

1. Należy zachować ostrożność podczas korzystania ze słuchawek, ponieważ nadmierne ciśnienie akustyczne może spowodować uszkodzenie lub utratę słuchu.
2. Istnieje ryzyko porażenia prądem, jeśli bateria zostanie wymieniona na baterię nieprawidłowego typu.
  - Zużyte baterie należy utylizować zgodnie z instrukcjami.
  - Wrzucenie baterii do ognia lub gorącego piekarnika, mechaniczne uszkodzenie lub rozszczelnienie baterii może spowodować wybuch.
  - Pozostawienie baterii w otoczeniu o bardzo wysokiej temperaturze może spowodować eksplozję lub wyciek łatwopalnego płynu lub gazu.
  - Bateria wystawiona na działanie bardzo niskiego ciśnienia może wybuchnąć albo stracić szczelność, co może prowadzić do wycieku łatwopalnego płynu i/lub gazu.
3. Temperatura EUT : 0°C~+45°C (samodzielnie), 0°C~+40°C (z adapterem).
4. Aby zapobiec możliwemu uszkodzeniu słuchu, nie słuchaj przy wysokim poziomie głośności przez długi czas.



Wysokie ciśnienie akustyczne grozi uszkodzeniem słuchu. Nie należy słuchać wysokich poziomów głośności przez dłuższy czas.

## Zakres częstotliwości (RF):

Bluetooth: 2400-2483,5 MHz (TX/RX);

## Maks. moc nadawania:

BT(EDR): 8,48 dBm

BLE: 2,63 dBm

## DEKLARACJA ZGODNOŚCI UE

Pełny tekst deklaracji zgodności UE można znaleźć pod następującym adresem:

<https://www.infinixmobility.com/cere/declaration>